




UNIDRIVE SP

Winding-unwinding solution with cell

Quick start commissioning guide

UNIDRIVE SP

Cell winding-unwinding solution

 Incorrect operational procedures may cause serious body injuries or material damages. This guide may be used only by qualified personnel able to comply with the safety precautions related to electronic drives. See the installation and the commissioning manual that may be found on the CD ROM supplied together with the variable speed drive.

UNIDRIVE SP

Contents

1 - GENERAL INFORMATION	4
2 - SM MODULE INSTALLATION	5
2.1 - Access to terminal blocks	5
2.2 - Module installation	5
3 - CONNECTIONS	6
3.1 - Power connection	6
3.2 - Encoder connection	7
3.3 - Control connection	8
4 - PARAMETER-SETTING	10
4.1 - Display and keypad	10
4.2 - Selection and modification of a parameter	11
4.3 - Access level.....	12
4.4 - Modification of the operating mode.....	12
4.5 - Return to winding/unwinding factory settings	12
5 - COMMISSIONING	13
6 - SMARTCARD	18
7 - DIAGNOSTICS	19

UNIDRIVE SP

Cell winding-unwinding solution

1 - GENERAL INFORMATION

The SP EDL CEL option module is pre-programmed with winding/unwinding function controlled by linear speed.

It comprises :

- a UNIDRIVE SP variable speed drive,
- a SM-EDL CEL module.

Note : If the Winding-unwinding solution is managed by a field bus, see the entire manual that may be found on the CD Rom supplied together with the drive.

Operating principle :

The principle consists in managing or in receiving a line speed reference and in measuring the coil radius by means of an external cell. This allows the drawing up of a speed reference for the motor, taking into account the ratio of the machine drive.

The system operates in open loop (□) and in closed loop (■ or ▣), for synchronous or asynchronous motorisations with all types of encoders.

The coil driving may be axial or tangential. For tangential driving, the motorisation will be located on the coil blank or on the bench grinder blank.

UNIDRIVE SP

Cell winding-unwinding solution

2 - SM MODULE INSTALLATION


•Size 3 or 4





• The drive must be powered down.

2.1 - Access to terminal blocks

• Size 1




•Size 2



CAUTION :

Dismantle the internal RFI filter on a drive of size 3 or 4, fed with power by a mains supply without earthing (IT conditions). If an external RFI filter is used or an additional motor earth protection is used, it is not necessary to remove the internal filter.

2.2 - Module installation



- Install the SM-EDL CEL module in the lowest possible location and press gently on the module until hearing a click.

- If necessary, to dismantle a module, press at the same time on both sides of the module and remove it.

UNIDRIVE SP

Cell winding-unwinding solution


3 - CONNECTIONS

3.1 - Power connection

Power supply for an AC 3-phase mains supply, applicable to the safety standard EN 954-1 Categ. B or 1.

CAUTION :

Before making the power connection, be aware of the location of the drive terminal blocks (different depending on their size). If necessary, see section D of the manual supplied together with the drive.



(1) For size 1, a single terminal block (48V, -DC, +DC, BR). Connect the resistor between +DC and BR.

(2) The thermal relay is not necessary for the resistors that may be integrated into the heater.

(3) Terminal 31 : safety input/disabling.

When this input is open, it disables the drive. Its conception is so that even in case of failure of one or many components, the absence of the torque on the motor shaft should be guaranteed with a very high level of integrity.


▲ For detailed instructions or for schemas according to the safety standard EN 954-1 category 2 or 3, see section D of the installation and commissioning manual that may be found on the CD ROM.

UNIDRIVE SP

Cell winding-unwinding solution

3.2 - Encoder connection

Drive HD 15	□ and ◻ modes				
	Incremental	Sincos	Sincos - hiface link	Sincos - EndAt or SSI link	EndAt or SSI
1	□ : B or F	Cos	Cos	Cos	-
	◻ : A or F				
2	□ : B\ or F\	CosRef	CosRef	CosRef	-
	◻ : A\ or F\				
3	□ : A or D or R	Sin	Sin	Sin	-
	◻ : B or D or R				
4	□ : A\ or D\ or R\	SinRef	SinRef	SinRef	-
	◻ : B\ or D\ or R\				
5	C or O or Z	-	Data	Data	Data
6	C\ or O\ or Z\	-	Data\	Data\	Data\
7	◻ : U	-	-	-	-
8	◻ : U\	-	-	-	-
9	◻ : V	-	-	-	-
10	◻ : V\	-	-	-	-
11	◻ : W	-	-	Clock	Clock
12	◻ : W\	-	-	Clock\	Clock\
13	+5V or +8V or +15V				
14	0V				
15	Motor thermal probe CAUTION : Internal link pin 15 and terminal 8 of the drive. Connect one or another.				



Example : encoder in quadrature


Ref.pct.	Designation	Ref.pct.	Designation
1	Motor thermal probe	1	0V
2	-	2	+5V or +8V or +12V
3	-	3	A
4	U	4	B
5	U\	5	C or O or Z
6	V	6	A\
7	V\	7	B\
8	W	8	C\ or O\ or Z\
9	W\	9	-
10	A	10	-
11	C or O or Z	11	Shielding (*)
12	C\ or O\ or Z\	12	-
13	A\		
14	B		
15	B\		
16	+5V or +8V or +15V		
17	0V		
	Shielding (*)		

(*) Depending on the encoder supplier, the shielding may be different from that indicated in the table. If there is no shielding terminal available, connect the shielding to 360 at the connector level.

UNIDRIVE SP

Cell winding-unwinding solution

3.3 - Control connection



CAUTION:

If the motor probe is connected to pin 15 of the HD-15 connector (see encoder connection), terminal 8 of the drive is no longer available.

⚠ In factory settings, UNIDRIVE SP is set in positive logic. The association of a drive with a different command logic may cause the sudden start of the motor.

UNIDRIVE SP

Cell winding-unwinding solution

5 Coil radius measurement ($\pm 10V$ analogue)

6 It is used to measure the radius of a coil by means of a cell

10 Forward run validation input (SM-EDL CEL)

It is used to validate the forward run line speed reference

11 Forward Run/Stop input (SM-EDL CEL)

It gives the forward run or stop command

24 Zero speed output

It informs that the motor is at zero speed

25 Drive reset input

It resets the drive faults

26 Run by pulse input

It selects the run by pulses

28 Reverse Run/Stop input

It gives the reverse run or stop command

41 Relay output

42 When the contact is open, the drive is powered down or stopped


UNIDRIVE SP



Cell winding-unwinding solution

4 - PARAMETER-SETTING


4.1 - Display and keypad

•LED display



Ref.	Function
(A)	It is used to display : - the drive operating status, - the adjustment parameters, from the parameter menu.
(B)	It is used to display: - the operating mode, - the parameter content, - the trip state code.
(C)	Touche Mode is used to pass from the normal mode to the parameter-setting mode.
(D)	The 2 arrows  are used to move under the lower display in order to modify its value or to move from one menu to another. The 2 arrows  are used to display in an increasing or decreasing order the parameters or their values.
(E) (F) (G)	In keypad mode, these keys are used for the commands : - Run, - Stop, drive reset, - Inversion of the direction of rotation.












•Indications on the operation

	Comment
Auto/tunE	Ongoing auto-tuning phase
dEC	Deceleration after a stop command
inh	- The drive is disabled, it may not start the motor - Free wheel stop
rdY	- The drive is enabled, it is waiting for a command - The motor is ready to turn
run	The motor is controlled by the drive
StoP	The drive maintains the motor torque at zero speed
triP	The drive is stopped, it does not control any longer the motor. The trip state code is displayed on the lower display

UNIDRIVE SP

Cell winding-unwinding solution

4.2 - Selection and modification of a parameter

Action	Comment
	Power-up Disabled drive (terminal 31 opened) (initial status)
	① : Access to parameter-setting mode. The parameter 0.10 flashes. ② : The keys  and  are used to access the parameter to be modified. For instance, select parameter 0.04 .
	③ : Access to the parameter modification. The parameter number does not flash any longer. Its value is indicated on the the lower display (the lowest value digit flashes). ④ : Maintain the key pressed in order to display quickly the parameter value. The final adjustment is made by quick presses on the same key. For more quickness, we may move to modify the other digits by  or  .
	⑤ : The new value of 0.04 is stored Press  or  in order to select a new parameter to be modified.
	⑥ : Return to the initial status of the drive.

Note : In parameter-setting mode, if the user stops inputs for 4 minutes, the display stops flashing and returns automatically to the initial status of the drive.

UNIDRIVE SP

Cell winding-unwinding solution

4.3 - Access level





In factory settings, only menu 0 is accessible by the user (parameters **0.00** to **0.50**).


To access other menus :

- select the parameter **0.49** : its value is L1,

- modify its value of **0.49** to " L2 ". The left and right arrows of the keyboard are active at present, and the menus 1 to 22 are accessible (parameters **1.01** to **22.29**).


4.4 - Modification of the operating mode


Parameter	Settings	Description	Validation
0.00	1253 or 1254	European configuration, mains supply of 50 Hz or USA configuration, mains supply of 60 Hz	Press the Reset  key
0.48	OPEn LP (1) or CL VECT (2) or SERVO (3) or rEgEn (4)	Open loop  or Vector control in closed loop  with asynchronous motor or Servo mode  with Brushless motor or Regenerative mode (not used)	

 • This procedure of modification of the operating mode causes the return to factory settings of the parameters corresponding to the new mode, including the motor parameters (it is necessary to set the motor parameters before starting). The modification of the operating mode must be made with the variable speed drive stopped or disabled.

• Before following this procedure, check that the system safety is adequate.

4.5 - Return to winding/unwinding factory settings

Parameter	Settings	Description	Validation
0.00	1233 or 1244	European factory setting configuration (50 Hz) or USA factory setting configuration (60 Hz)	Press the Reset  key
0.29	2047	EDL CEL program initialisation. The value 2047 is not visible on the display that passes from 2047 to 0. The return of 0.29 to 0 indicates the fact that the program initialisation is performed.	-

 • Check that the motor is stopped and that the system safety is adequate.

UNIDRIVE SP

Cell winding-unwinding solution

5 - COMMISSIONING

Powered down drive, check that...

- The drive is disabled
- The run command is not validated
- The motor and the encoder are connected

Drive power-up

- The drive displays " inh "
- If the drive stops "trip", see art. 7 " diagnostics "

Operating mode selection


- **0.00** : enter the value 1253 for an European configuration (mains supply 50 Hz) or enter the value 1254 for an USA configuration (mains supply 60 Hz)
- **0.48** : enter the mode OPEn.LP (1) or CL.VECt (2) for the asynchronous motor or SerVO (3) for the servo motor
- Press the Reset key

SM-EDL CEL program initialisation

- **0.29** : enter the value 2047
- After initialisation, **0.29** returns to 0

Enter the motor parameters indicated on the nameplate

- **0.42** : Poles [Auto (0), 2POLE (1), 4POLE (2), 6POLE (3) etc...]
 - **0.43** : Power factor ($\cos \varphi$) +
 - **0.44** : Motor rated voltage (V) +
 - **0.45** : Rated speed with load (min^{-1}) + or motor thermal time constant (see the motor catalogue)
 - **0.46** : Motor rated current (A) + / Stall current (A)
 - **0.47** : Motor rated frequency (Hz) +
- Pay attention to the motor connection (star or delta)**




UNIDRIVE SP

Cell winding-unwinding solution



A


YES Possibility to disconnect the motor ? NO



Auto-tuning with rotation


-  Check that the motor is stopped and disconnected from load. If there is a brake, check that it is released.
- Check that there is no danger for persons and goods.
- Once the procedure has ended, the motor will automatically stop in free wheel.

• The procedure may be interrupted at any moment by a stop command, by pressing the stop button of the keyboard, or by activating the disable circuit.

  Irrespective of the reference and of the direction of rotation required, the auto-tuning procedure drives the motor clockwise at 2/3 of its rated speed.

 Irrespective of the reference and of the direction of rotation required, the motor performs a low speed turn.

  : Full measurement of the motor characteristics and adjustment of the current loop gains.

 : Measurement of the phase angle of the slave encoder (**0.43**), and setting of the current loop gains.

- **0.40** : set to 2.
 - Enable the drive (close B31).
 - Give a run command (close B28).
 - The motor starts rotating. Wait for the full stop.
- Disable again the drive, and suppress the run command (open B31 and B28). Connect the motor to the load.

Auto-tuning without rotation (and only)

Reduced measurement of the motor characteristics and adjustment of the current loop gains.

Check that the motor is stopped before proceeding to auto-tuning.

- **0.40** : set to 1.
 - Enable the drive (close B31).
 - Give a run command (close B28).
- The drive displays alternately " Auto " then " tunE " during the auto-tuning phase.
- Disable again the drive, and suppress the run command (open B31 and B28).

CAUTION () :

This auto-tuning mode does not allow the verification of the adequate connection between encoder and motor (no detection of inversion or phase breaking).

C

UNIDRIVE SP

Cell winding-unwinding solution



Cell scaling

To adapt the external radius measurement to the application, it is necessary to proceed to scaling by the following procedure :

- Implement or simulate a coil without load (min radius), read and note the value of parameter **0.15**.
- Set **0.21** to this value, then set the min radius **0.16** in mm.
- Implement or simulate a coil with load (max radius), read and note the value of parameter **0.15**.
- Set **0.22** to this value, then set the max radius **0.17** in mm.

The radius visualisation in mm is possible with **0.11**.

Enter the values of the parameters essential for the application

- **0.18**: Set the reverse maximum speed in $m \cdot \text{min}^{-1} \times 10$.
- **0.19**: Set the line speed by pulses in $m \cdot \text{min}^{-1} \times 10$.
- **0.20**: Set the forward maximum line speed in $m \cdot \text{min}^{-1} \times 10$.
- **0.24**: Set the acceleration ramp of the line speed in seconds for 1000 min^{-1} .
- **0.25**: Set the deceleration ramp of the line speed in seconds for 1000 min^{-1} .
- **0.27**: Set the value 0, if the product comes over the coil, and the value 1, if the product comes under the coil.
- **0.28**: Set the coil reduction (between the motor and the chuck driving axle) $\times 100$.

Storing

- **0.00**: Enter the value 1000
- Press the Reset  key


Commissioning

- Enable the drive (close B31).
- For a forward run command by pulses, close terminal 26 of the drive and terminal 11 of SM-EDL CEL.
- For a reverse run command by pulses, close terminals 26 and 28 of the drive.
- For a forward run command, close terminals 10 and 11 of SM-EDL CEL.
- For a reverse run command, close terminal 28 of the drive.
- To stop the motor, suppress the run command, then disable the drive.

UNIDRIVE SP

Cell winding-unwinding solution

If the encoder is not a standard LEROY-SOMER incremental encoder, follow the indications below:



Enter the encoder characteristics

• **3.34 : ELPR (0 to 50000)**

Quadrature : enter the number of points by turn

Frequency/direction or forward/reverse : enter the number of points by turn divided by 2.

Sincos : enter the number of sinusoids by turn.

• **3.36 : Voltage**

Enter the encoder power supply voltage : 5V (0) or 8V (1) or 15V (2)

CAUTION:

Feeding an encoder with an excessive voltage can damage it.

• **3.38 : Type**

Enter the type of encoder used : Ab (0) : quadrature encoder

Fd (1) : frequency-direction

Fr (2) : fwd-reverse

Ab.SERvo (3) : quadrature encoder + switching paths

Fd.SERvo (4) : frequency-direction + switching paths

Fr.SERvo (5) : fwd-reverse + switching paths

SC (6) : SinCos encoder without serial link

A

In order to proceed to commissioning, resume page 14

UNIDRIVE SP

Cell winding-unwinding solution

(B1)

0.49 = L2 (1)

Enter the encoder characteristics

SinCos encoder with Hiperface or EndAt serial link or EnDat encoder	SinCos encoder with SSI link or SSI encoder
<ul style="list-style-type: none"> • 3.41 : Auto-configuration Enter the On (1) value for an auto-configuration of the encoder parameters when powering up (3.33, 3.34 and 3.35). • 3.36: Voltage Enter the encoder power supply voltage: 5V (0) or 8V (1) or 15V (2). CAUTION: Feeding an encoder with an excessive voltage can damage it. • 3.37 : Transmission speed Enter the serial link speed (save for SinCos encoder with Hiperface link) : 100 kbauds (0), 200 kbauds (1), 300 kbauds (2), 400 kbauds (3), 500 kbauds (4), 1000 kbauds (5), 1500 kbauds (6), 2000 kbauds (7), 4000 kbauds (8). • 3.38 : Type Enter the type of encoder used : SC.Hiper (7) : SinCos with Hiperface, EndAt (8) : EndAt, SC.EndAt (9) : SinCos with EnDat link. 	<ul style="list-style-type: none"> • 3.41 : Selection of SSI format Enter the OFF (0) value to select the Gray SSI code format or On (1) to select the SSI binary format. • 3.33 : number of turns (number of bits) Enter the maximum number of encoder turns. Ex. : if 3.33 = 5, the maximum number of turns will be of 2⁵. • 3.35 : Resolution (number of bits) Enter the resolution of the serial link (number of bits used to represent an encoder turn). • 3.36: Voltage Enter the encoder power supply voltage : 5V (0) or 8V (1) or 15V (2). CAUTION: Feeding an encoder with an excessive voltage can damage it. • 3.37 : Transmission speed Enter the link speed : 100 kbauds (0), 200 kbauds (1), 300 kbauds (2), 400 kbauds (3), 500 kbauds (4), 1000 kbauds (5), 1500 kbauds (6), 2000 kbauds (7), 4000 kbauds (8). • 3.38 : Type Enter the type of encoder used : SSI (10) : SSI encoder, SC.SSI (11) : SinCos with SSI link.

(A)

In order to proceed to commissioning, resume page 14


UNIDRIVE SP

Cell winding-unwinding solution




6 - SMARTCARD

SMARTCARD is supplied in standard version together with UNIDRIVE SP.



It is used to save the drive parameters on SMARTCARD, or to load parameters in the drive by means of SMARTCARD.



• Drive saving

Parameter	Settings	Description	Validation
0.00	1000	Storage of all the drive parameters	Press the Reset  key
0.30	Prog (2)	Storage of the drive parameters on SMARTCARD	Press the Reset  key After the transfer, 0.30 returns to 0.
0.29	3333	Storage of the drive parameters on SMARTCARD (menus 20, 70 and 71)	Press the  key

• SMARTCARD loading

Parameter	Settings	Description	Validation
0.30	REAd	Loading of the SMARTCARD parameters into the drive	Press the Reset  key After the transfer, 0.30 returns to 0
0.29	6666	Loading of the SMARTCARD application parameters into the drive (menus 20, 70 and 71)	Press the  key

UNIDRIVE SP

Cell winding-unwinding solution

7 - DIAGNOSTICS

• Indications on winding-unwinding (reading parameters only) :

Parameter	Indication	Unit
0.10	Measured motor speed	min ⁻¹
0.11	Product radius	mm
0.12	Line speed	x 0,1m.min ⁻¹
0.13	Coil speed	min ⁻¹
0.14	Mechanical reduction	x 0,01
0.15	Coil radius measurement	points

• Indications on trip state

If the drive stops, the output bridge of the drive is inactive and the drive does not control any longer the motor.

The upper display indicates " triP " and the lower display indicates the fault type.

Mnemonic display	EDL fault	Solution
th	Motor thermal probe	The EDL CEL solution manages the motor thermal probe in standard version. If there is no probe connected, set 0.49 = L2 (1), then 7.15 = Volt (6). If the probe is connected, the motor temperature is too high.
t127	<ul style="list-style-type: none"> • Fault on RS485 link in RTU modbus • A problem occurred on the signal reception 	<ul style="list-style-type: none"> • Check the cabling • Check the drive configuration, the transmission speed, the addressing etc...

Note : For the other drive faults, see section K of the commissioning manual that may be set on CD-ROM.

UNIDRIVE SP

Cell winding-unwinding solution

• Terminal block configuration

	Function	Terminal	Source/ Dest.	Digital inversion	Assignment
UNIDRIVE SP	Coil 1 ray measurement	5 and 6	7.10	7.09	18.08 (0.15)
	Zero speed	24	8.21	8.11	10.03
	Drive reset	25	8.22	8.12	10.33
	Run by pulses	26	8.23	8.13	19.42
	Free	27	8.24	8.14	-
	Reverse Run/Stop	28	8.25	8.15	19.48
SM-EDL CEL	Forward Run validation	10	-	-	19.45
	Forward Run/Stop	11	-	-	19.47
	Min radius reached	12	-	-	18.31
	Max radius reached	13	-	-	18.32

UNIDRIVE SP
Cell winding-unwinding solution

Notes

UNIDRIVE SP
Cell winding-unwinding solution

Notes

UNIDRIVE SP
Cell winding-unwinding solution**Notes**



MOTEURS LEROY-SOMER 16015 ANGOULÊME CEDEX - FRANCE

338 567 258 RCS ANGOULÊME
S.A. au capital de 62 779 000 €

www.leroy-somer.com